

Continue



[illegible]

Duplex 740 c1914-1939 Patent Klapp Reflex 1924-1939 Patent Klapp Reflex Tropen (Tropical) 1924-1939 Photoklapp Stereo-Automat c1925 Photoknips (Nr. 100, Model A) c1924-1933 Photoknips (Nr. 200, Model B) 1925-1936 Photoknips No.1 1918-1921 Photoknips No.2 1918-1921 Photorex 1912-1918 Pioneer 1927-1936 Pioneer
Automat c1934-1940s Plan-Paff Reflex 10 1921-1932 Plan-Paff Reflex 3 1921-1932 Plan-Paff Reflex 4 1921-1932 Plan-Paff Reflex 7 1921-1932 Plan-Paff Reflex 9 1921-1932 Republic Full-View c1921 Roll-Paff Reflex Luxus 1921-1927 Roll-Paff-Reflex No.20 1921-1932 Roll-Paff-Reflex No.21 1921-1932 Roll-Paff-Reflex No.21H 1928-1932
Serien-Reflex 2110 1928 Serien-Reflex 2113 1929 Serien-Reflex 2120 1928 Serien-Reflex Tropen 2120 (Tropical) 1928 Sport 1810 1931-1939 Sport 1820 1928-1939 Sport 1830 1931-1939 Sport-Roll-Film-camera 1936 Stereo-Automat (Nr. 1715) 1925-1939 Ultrix Duplex No.1560 1924-1935 Ultrix No.1460 1923-1935 Ultrix
No.1470 1923-1935 Ultrix No.1475 1928-1935 Ultrix No.1485 1928-1935 Ultrix No.1490 1923-1935 Ultrix No.2960 1928-1930s Ultrix Simplex 1360 1924-1933 Ultrix Simplex 1360 Luxus 1931-1932 Ultrix Simplex 1370 1924-1935 Ultrix Stereo No.1690 1925-1939 Ultrix-Automat (Nr. 1250) 1925-1932 Universal c1924 Venus 610 1920-
1935 Victor 510 1924-1939 Victor 520 1920-1939 Victor 530 1920-1939 Zweiverschluss Duplex (1010, 6.5x9, f2.9) 1928-1939 Zweiverschluss Duplex (1010, 6.5x9) 1928-1939 Zweiverschluss Duplex (1020, 9x12) 1927-1939 Zweiverschluss Duplex (1030, 10x15) 1928-1939